easywalker

www.easywalker.nl

DUO Carrycot



BS 7409: 1996
BS EN 1466

EN1466
approved

Dutch Design
Made in China

easywalker

Instructions

EN

DUO Carrycot

















carrycot

4,9 kg

max 9 kg

80cm x 40cm x 56cm













WARNING! IT MAY BE DANGEROUS TO LEAVE YOUR CHILD UNATTENDED

Children should be harnessed in at all times.
Ensure child is clear of moving parts whilst making adjustments.
This vehicle requires maintenance by the user.
Incorrect folding/overloading and the use of non approved accessories may break or damage this product.

ALWAYS READ THE INSTRUCTIONS



CARELESSNESS CAUSES FIRE

Tested to ensure compliance with the Furniture and Furnishings (Fire) (Safety) Regulations. Conforms to BS 7409:1996 and EN 1888:2003
EasyWalker products: Made in China
for UK distributor: Bibs and Stuff, Surrey, England. RH1 5EW

INSTRUCTIONS

3 Assembling the EasyWalker DUO carrycot
3 Contents of the box
4 Attaching the carrycot to the frame
5 Removing the carrycot from the frame
5 Using the EasyWalker DUO carrycot
5 Rain cover
6 Mosquito net

Assembling the EasyWalker DUO carrycot

⚠ WARNING: Keep plastic covers away from babies and children to avoid suffocation.
⚠ WARNING: Do not add a mattress thicker than 50 mm in the carrycot.
⚠ WARNING: Check that the carrycot is properly attached to the supporting frame and that it is securely fixed before you use the EasyWalker DUO.
IMPORTANT: The EasyWalker DUO carrycot is intended to be used for children from birth to the age of 6 months or 9 kg.
IMPORTANT: Only use the EasyWalker DUO carrycot or accessories approved foruse by EasyWalker on the EasyWalker DUO.IMPORTANT: Ensure that the parking brake is engaged when you place your childrenin or remove them from the EasyWalker DUO.
IMPORTANT: When assembling the EasyWalker DUO carrycot a child should not be in the cot.

Contents of the box

The following items must be contained in the EasyWalker DUO carrycot box.
1 carrycot with sun canopy and cover.
1 mattress with fleece and cotton cover.
1 rain cover.
1 mosquito net.
1 sheet cover.
2 connection tubes.
1 instruction leaflet.
In order to attach two carrycots onto the EasyWalker DUO, you will also need the long connection tubes, from the EasyWalker DUO box.

If items are missing, immediately contact the shop where you purchased the pushchair.

TIP: Use the cardboard packaging as a mat whilst assembling the item.
TIP: If the instructions say left or right, this is always meant when looking from behind the EasyWalker DUO push-bar.
TIP: All components are designed to fit together so you do not need to use force. If something is not working, read the instructions again and try once more. If something still does not work then ask for help in the shop where you purchased the item or watch the instruction video on www.easywalker.nl

The EasyWalker DUO carrycot is simple to assemble (image 1+2). Before using for the first time, take the carrycot out of the box, take the cover off the carrycot and remove the accessories, the mattress and the inside covers. Pull the fastener on the bar (nearest to the head-end) in the direction of the head-end until it clicks, left and right, into the metal holder. Pull the fastener on the bar (nearest to the foot-end) in the direction of the foot-end until it clicks, left and right, into the metal holder.

Attach the inside covers to the carrycot again with Velcro. Put the mattress back in the carrycot. You can now choose whether you want the fleece or cotton side uppermost. Turn the sun canopy upwards by pushing the black buttons on both sides of the sun canopy and simultaneously turning the canopy upwards. Ensure that the canopy cannot turn any further and release the buttons (image 3+4). Reattach the cover over the carrycot (image 4.

Attaching the carrycot to the frame

Engage the parking brake of the EasyWalker DUO (image 6). If you want to attach one carrycot to the EasyWalker DUO, this can only be done on the right-hand side. Remove the seat, the sun canopy and the bumper bar from the frame. If required, you can leave the left-hand seat and the left-hand side of the sun canopy in place. See the previous pages for instructions on the removal of the seats, the sun canopy and the bumper bar. Place the short connection tubes with open clips, on the right-hand side against the frame. Position between the two caps and shut the left and right clips of both connection tubes (image 7+8). Lift up the carrycot using the grips in the sun canopy and under the foot-end. Slide the hooks (under the head-end) over the tube at the front of the frame, above the footplate. Now pull the hand grip under the foot-end backwards so that the clips under the foot-end open and, at the same time, push the clips over the connection tube. Let go of the hand grip under the foot-end (image 11). The clips shut by themselves around the connection tube. If required, a second carrycot can be fixed to the frame. In order to do so, remove the entire seat and sun canopy from the frame. Instead of the short connection tubes, you would now use the long connection tubes (image 9+10). Connecting the carrycot to the left-hand side is done in the same way as described above.

⚠ WARNING: Check that the carrycot is properly attached to the supporting frame and that it is securely fixed, before you use the EasyWalker DUO.

IMPORTANT: A small child has very sensitive skin. Never leave your child in the EasyWalker DUO in the sun without the sun canopy on.

Removing the carrycot from the frame

Engage the parking brake of the EasyWalker DUO. To remove the carrycot from the frame, hold onto the carrycot by the hand grips in the sun canopy and under the footend.
Now pull the hand grip (under the foot-end) backwards so that the clips under the foot-end open and, at the same time, lift the foot-end away from the connection tube. Slide the carrycot towards the head-end, away from the tube at the front of the frame, above the footplate.

TIP: The carrycot has four black feet on the underside so that it can be used as a cot without a supporting frame.
TIP: The hand grip in the sun canopy is suitable for lifting the carrycot if it has been lifted up completely. In the bag, at the foot-end, there is an extra hand grip so that you can safely carry the carrycot.

Using the EasyWalker DUO carrycot

IMPORTANT: Avoid dangerous situations. Always use the wrist band attached to the pushbar. Take your child out of the EasyWalker DUO carrycot if you go up or down stairs, escalators or steep hills.
IMPORTANT: Do not use the EasyWalker DUO carrycot if any part is broken, torn, incomplete or does not seem to be functioning correctly.
IMPORTANT: The EasyWalker DUO carrycot is not designed for use when jogging or roller skating.
IMPORTANT: A small child has very sensitive skin. Never leave your child in the EasyWalker DUO in the sun without the sun canopy on.
IMPORTANT: The EasyWalker DUO carrycot is not a car seat. Transport your child in the car in an approved car seat or in the carrycot with an approved car adapter.

Rain cover

The EasyWalker DUO carrycot is supplied, as standard, with a rain cover. Place the rain cover so that the stitching rests on the front and rear edges of the sun canopy and the ventilation window is by the opening. Shut the sides by closing the Velcro fastenings

and closing the popper. The elastic on the underside rests on the lower edge of the carrycot (image 44).

TIP: The rain cover has reflective stitching so that you are visible to other road users in the dark and during bad weather.

IMPORTANT: The rain cover has a ventilation window at the front that can be closed using Velcro. You can open and secure the window with the button and the elastic loop.
IMPORTANT: Do not let your child sit under the rain cover unnecessarily. Ensure that your child does not get too hot.

Mosquito net

The EasyWalker DUO carrycot is supplied, as standard, with a mosquito net. Place the mosquito net over the carrycot so that it connects properly to the carrycot (image 13).

The Netherlands / Head office
Belgium / Luxemburg
EasyWalker bv
P.O. Box 138
1380 AC WEESP
+31-294-230351
www.easywalker.nl
www.easywalker.be
info@easywalker.nl
UK / Ireland

Distributed in the UK & Ireland by

Bibs and Stuff
+44-1293774924
www.bibsandstuff.com
Sales@bibsandstuff.com
26 Bonehurst Rd,
Salfords Ind Est, Nr Redhill, Surrey, RH1 5EW
England